



PA0	PA1	PA2	PA3	PA4	PA5	PA6	PA7	PB5
RY4 BOOST	RY5 BUCK	RV6 OUTPUT	BZ	LED3	LED1	MODEL SELECT SIGNAL	DC POWER	RY1 CHARGE
PB6	PB7	PC0	PC1	PC2	AN0	AN1	AN2	AN3
S.D RD	B.L TX	INV.	S1/S2	S3	L.V. & L.I.V.	B.V. & MODEL SENSE	L.I.	MODEL SENSE & OUTPUT SHOR