

CONTENTS

Chapter 1	Introduction	9
1-1	MAINBOARD SPECIFICATION	10
1-1-1	PROCESSOR	10
1-1-2	CHIPSET	10
1-1-3	ADVANCED HIGH PERFORMANCE DRAM CONTROLLER	10
1-1-4	FULL FEATURED ACCELERATED GRAPHICS PORTS	10
	(AGP) CONTROLLER	10
1-1-5	MULTI-I/O FUNCTION	10
1-1-6	EXPANSION SLOTS	11
1-1-7	AWARD BIOS V6.0, SUPPORTING	11
1-1-8	SOUND CONTROLLER	11
1-1-9	POWER MANAGEMENT	11
1-1-10	FORM FACTOR	12
1-1-11	HARDWARE MONITORING	12
1-1-12	OTHERS	12
1-2	MAINBOARD LAYOUT	13
1-2-1	MAINBOARD LAYOUT --- 75KAV	13
1-2-2	MAINBOARD LAYOUT --- 75KAV-X	14
1-3	CHIPSET DIAGRAM	15
Chapter 2	Hardware Setup	17
2-1	CPU INSTALLATION	18
2-2	MEMORY INSTALLATION	19
2-3	ACCELERATED GRAPHICS PORT(AGP) PRO INSTALLATION	21
2-4	HDD/FDD INSTALLATION	22
2-5	SWITCH SETTING FOR CPU FREQUENCY AND VOLTAGE ...	24
2-5-1	INFORMATION ON AMD SOCKET 462 PROCESSOR	24
2-5-2	CPU EXTERNAL FREQUENCY SETTING (BY SW1)	25
2-5-3	BUS RATIO SELECT (BY SW2 DIP1-4/JP17)	26
2-6	JUMPER SETTING FOR DEVICES ON BOARD:	27

2-6-1 JUMPER JBAT1 FOR CLEARING CMOS DATA: 27

2-6-2 JP1/JP2 USB PORT SELECT 28

2-6-3 JP3 FOR FACTORY TEST ONLY 28

2-6-4 JP7 POWER LOST RESUME 29

2-6-5 JP9 USB WAKE UP 29

2-6-6 JP10/JP11 MEMORY MODULE VOLTAGE SELECT 30

2-7 CONNECTORS CONFIGURATIONS 31

2-7-1 ONBOARD FAN CONNECTOR (FAN1/FAN2/FAN3) 31

2-7-2 WAKE ON LAN FUNCTION (WOL1) 32

2-7-3 CD-ROM AUDIO CONNECTOR (CD-IN1/CD-IN2) 32

2-7-4 THERMAL SENSOR CONNECTOR (RT2) 33

2-7-5 HEADER J3&J4 34

2-7-6 CHASSIS PANEL CONNECTOR 37

2-7-7 ATX POWER SUPPLY CONNECTOR 38

2-7-8 PS/2 MOUSE AND PS/2 KEYBOARD 38

2-7-9 SERIAL PORT CONNECTOR 39

2-7-10 SECOND USB HEADER (USB2) 40

2-7-11 IRQS DESCRIPTION FOR VARIOUS DEVICES 41

2-8 VOICE DIAGNOSTIC FUNCTION---ONLY FOR 75KAV-X 42

2-8-1 VOICE DIAGNOSTIC FUNCTION SELECT (BY JP4/JP5) 43

2-8-2 VD-TECH CONTROLLER CHIP (BY JP8) 43

Chapter 3 Software Setup 45

ABOUT SUPPORT CD 45

3-1 VIA CHIPSET DRIVER INSTALLATION (4-IN-1 DRIVER) 46

3-2 AC97 AUDIO CODEC DRIVER INSTALLATION 49

3-3 HARDWARE MONITOR INSTALLATION 51

Chapter 4 BIOS Setup 55

THE BIOS 55


4-1 WHAT IS BIOS SETUP 56

4-2 HOW TO RUN BIOS SETUP 56

4-3 WHAT IS CMOS 56

4-4 WHAT IS POST 56

4-5 BIOS UPGRADE	56
4-5-1 BEFORE UPGRADING BIOS	57
4-5-2 UPGRADE PROCESS	57
4-6 BIOS SETUP°XCMOS SETUP UTILITY	61
4-6-1 STANDARD CMOS SETUP	62
4-6-2 ADVANCED BIOS FEATURES	65
4-6-3 ADVANCED CHIPSET FEATURES	70
4-6-4 INTEGRATED PERIPHERALS	75
4-6-5 POWER MANAGEMENT SETUP	79
4-6-6 PNP / PCI CONFIGURATION	86
4-6-7 SMARTDOC ANTI-BURN SHIELD	90
4-6-8 FREQUENCY/VOLTAGE CONTROL	93
4-6-9 LOAD OPTIMIZED DEFAULTS	94
4-6-10 SET SUPERVISOR / USER PASSWORD	96
4-6-11 SAVE & EXIT SETUP	97
4-6-12 EXIT WITHOUT SAVING	97
Appendices	98
APPENDICES-1 TECHNICAL TERMS INTRODUCTION	99
APPENDICES-2 IDENTIFYING BIOS VERSION AND	100
BIOS PART NUMBER	100
APPENDICES-3 IDENTIFYING MAINBOARD \ MODEL	102
NUMBER	102



ITEMLIST CHECKUP

- Mainboard
- Support CD
- User's Manual
- Bundled Bonus Pack CD
- Bundled Bonus Pack Manual
- Temperature Sensor Cable
- ATA66/100 IDE Cable
- RS232 Cable
- FDD Cable